



Parts:

A Battery Output	D Headrest Input
B Motor Connection	E Charging Port and Battery Indicator
C Headrest Output	F Battery and Bracket Zipper Access

1. Connect Battery Output (A) to Motor Connection (B)
2. All seats with power headrest, connect Headrest Output (C) to Headrest Input (D)
3. Adhere back flap to frame for a smooth finished look
4. You may access battery or charging port and battery indicator (E) connection through zipper located under LAF Recliner arm (F). For trouble shooting, please refer to your FreeMotion battery owner's manual or visit www.freemotionbattery.com.

