

## TYBEE OUTDOOR LOUNGE CHAIR 21C024A-CLB Assembly Instruction

Part	s List:		00111	Siy ii			
REF.	PART NAME	PART IMAGE	Q'TY	REF.	PART NAME	PART IMAGE	Q'TY
A	CHAIR BACK		1	D	WASHER	0	4
В	CHAIR BASE		1	E	ALLENWRENCH	<u> </u>	1
с	BOLT	C)	4				
nove and dise	E card the rear arm s				C	E	
	s not powder coate			E	C		
Step agai	nst attached parts list	to make sure all pa	arts are p	oresente	. Indentify all parts packed		

Step 2: Place a protective soft material on the floor, then lay chair base(B) placement down on floor.

Step 3: Then attach chair back(A)to the bottom as shown in diagram, using BOL T(C) and WASHER(D).

Step 4: After all bolts are aligned properly, tighten all bolts using ALLEN WRENCH(E). With a second person's Carefully place the sofa on your lap. Make sure the legs are on a flat surface.

NOTE: IT IS USER'S RESPONSIBILITY TO MAKE SURE ALL PARTS ARE ASSEMBLED AND TIGHTENED PROPERLY AND SECURELY.