HOW TO INSTALL TRIANGULAR FEET ON A SOFA

MAKE SURE AREA IS CLEAR OF OBSTICLES BEFORE ROLLING THE UNIT OVER .
FLIP UNIT OVER FORWARD EXPOSING THE BOTTOM OF THE UNIT .

GET THE LEGS AND SCREWS OUT OF THE BAG THEY COME IN .



LINE UP THE FEET SO
THEY ARE IN THE
CORNER WITH THE
SPACE FROM THE
EDGES BEING THE
SAME



PUT THE SCREWS IN THE HOLES IN THE FEET. USE A PHILLIPS SCREWDRIVER, OR DRILL TO TURN THE **SCREWS INTO THE WOOD FRAMING** UNTIL THE SCREWS are TIGHT.

