

Instruction Sheet for Modular Group

1. Ensure a suitable location has been selected for your modular before beginning assembly.
2. Wooden legs and U Clips are located inside the black dust cover at the bottom of pieces.
Unzip to remove the legs and clips.
3. Attach the wooden legs to the corresponding pre-drilled holes by hand turning in a clockwise direction until tight.
4. If required, plastic U Clips are included for connecting pieces together to prevent movement. The two U clips are installed into the base and hold pieces in place (see Figure 1).
5. The Ottoman does not include U Clips to enable it to be easily repositioned.
6. Your modular is now ready to use.

