## **JOFRAN** INC.

## ASSEMBLY INSTRUCTIONS & PARTS IDENTIFICATION


MODEL # 552-28

DINING TABLE

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment

- 2	Key Parts				
No	Code	Qty	Description		
1	552-28P24	1 pc	Table Top		
2	552-28P02	4 pes	Table Leg		
3	552-28P01F	4 pcs	Floor Glide		
4	552-28P26	4 pcs	Corner Block		
5	552-28P01H	6 sets	Hinge		
6	552-28P36	4 pcs	Leaf Support		

Hardware kit 552-28P01					
No		Qty			
A	0	Flat washer	8 pcs		
В	0	Lock washer	8 pcs		
c		Nut Ø8	8 pcs		
D	=3	Key wrench	1 pc		



## STEP 1

- Carefully lay Table Top upside down on a smooth flat surface to prevent scratches.
- Attach each Leg to each corner of the Table Top as shown in illustration. Insert a Flat Washer, Lock Washer and Nut on to the insert nut of each Leg
- Once all Legs are in place, fully tighten nuts by turning clockwise using provided Key Wrench until secure.