





# 1

use the bolts and allen key to fix chair legs

A	5606C-A side leg	 X 4
B	5606C-B bolt	 X 8
C	5606C-C allen key	 X 1



232245/232229

CARESSA CHAIR

# 2

