



A	PD5256-42TTL TABLE TOP (LEFT)		X1
B	PD5256-42TTB TABLE BASE		X1
C	PD5256-42TTP TOP PANEL (LEFT)/		X1
D	PD5256-42BLA AXIS (METAL)		X1
E	PD5256-42BCV COVER		X1
F	PD5256-42HD-F		X6
G	PD5256-42HD-G		X6
H	PD5256-42HD-H		X6
I	PD5256-42HD-I		X1
J	PD5256-42HD-J		X2





CONCORD EXTENSION COUNTER




254059/ D5256-42B  
254060/ D5256-42T

CONCORD BASE EXTENSION COUNTER TABLE  
CONCORD TOP EXTENSION COUNTER TABLE





Step 6



Step 7

C

Step 8

LOCKED

Step 9

Level Me

OPEN EXTENSION LEAF PROPERLY.  
DO NOT MOVE THE LEAF EITHER SIDE THEN DROP DOWN.  
CLOSE TWO MAIN LEAVES.

NOTE:  
THE TABLE SHOULD BE LOCKED IN POSITION AND LEVELLED USING SPIRIT LEVEL. (SPIRIT LEVEL NOT INCLUDED)  
LA TABLE DOIT ÊTRE VERROUILLÉE EN POSITION ET LAISSÉE À L'AIDE DU NIVEAU D'ESPRIT. (NIVEAU D'ESPRIT NON INCLUS)  
LA MESA DEBE ESTAR BLOQUEADA EN POSICIÓN Y NIVELADA USANDO EL NIVEL DEL ESPÍRITU. (NIVEL DE ESPÍRITU NO INCLUIDO)