





LIVINGSPACES

A	PD5256-42TTL TABLE TOP (LEFT)		X1
B	PD5256-42TTB TABLE BASE		X1
C	PD5256-42TTP TOP PANEL (LEFT)		X1
D	PD5256-42BLA AXIS (METEL)		X1
E	PD5256-42BCV COVER		X1
F	PD5256-42HD-F		X4
G	PD5256-42HD-G		X10
H	PD5256-42HD-H		X10
I	PD5256-42HD-I		X1
J	PD5256-42HD-J		X2




CONCORD EXTENSION COUNTER



254059/ D5256-42B
254060/ D5256-42T



CONCORD BASE EXTENSION COUNTER TABLE
CONCORD TOP EXTENSION COUNTER TABLE




WARNING:
ONLY THE HAND TOOLS
PROVIDED




Step 6



Step 7




Step 8



LOCKED

Step 9



WARNING: ONLY THE HAND TOOLS PROVIDED