


# ASSEMBLY INSTRUCTIONS

## Item No. : ARY-001



(1) Carefully remove all parts from box and remove all plastic covering from lamp parts.

(2) Place the Lamp Base (A) on the table.

(3) Attach the Harp (B) on the Socket.

(4) Place the Shade (C) on the Harp (B).

(5) Place the Metal Retainer (D) to lock on the Spider of Shade (C) and tighten in with the Finial (E).

CAUTION: TO REDUCE RISK OF FIRE.  
USE **MAX** 100-WATT 3-WAY TYPE A  
LAMP OR USE **MAX** 29-WATT 3-WAY  
SELF-BALLASTED LAMP OR LAMP ADAPTER.  
120V 60Hz AC ONLY MADE IN CHINA

## CAUTION: IMPORTANT SAFETY INSTRUCTIONS

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless the plug can be fully inserted. Do not alter the plug.

**Made in China**


Dear Customer,

Congratulations on your purchase of this quality lamp. It has been produced under the highest quality standards. Please read carefully the following precautions before using this lamp:

- When unpacking and assembling, be careful not to pull wire with full strength, as an incorrect connection could result.
- Only use the bulb and wattage specified in this instructions or on the label located on the socket.
- Do not attempt to replace bulb while the lamp is plugged into an electrical outlet.
- Do not use outdoors, or near water or other liquids.
- Unplug from outlet before removal of any parts and cleaning.
- Only use soft cloth for cleaning. Do not use any chemical or abrasive cleaners.
- Remove the cellophane cover from shade before use.
- During shipment, the socket cover may have become loose. Before inserting bulb, check to see that the socket cover is in place.

# INSTRUCTIONS D'ASSEMBLAGE

Numéro d'article: ARY-001



(1) Retirez soigneusement toutes les pièces de la boîte et enlevez toutes les pellicules de plastique des pièces de la lampe.

(2) Placez la Socle de lampe (A) sur la table.

(3) Fixez la lyre (B) sur la douille.

(4) Placez Abat-jour (C) sur la Lyre (B).

(5) Placez (D) les honoraires métalliques sur l'ombre (C) et serrer avec le fleuron (E).

ATTENTION: AFIN DE RÉDUIRE LE RISQUE D'INCENDIE,  
UTILISER UNE **MAX** AMPOULE TYPE A 3 VOIES DE 100  
WATTS OU UTILISER UNE **MAX** 3 VOIES DE 29 WATTS  
AUTOBALLASTEE LAMPE OU LAMPE ADAPTATEUR.  
120V 60Hz C.A. SEULEMENT FABRIQUE EN CHINE

## MISE EN GARDE : CONSIGNES DE SÉCURITÉ IMPORTANTES

Cette lampe portable possède une fiche polarisée (une lame est plus large que l'autre), qui accroît la sécurité du produit en réduisant le risque de décharge électrique. Cette fiche ne s'insère que d'une façon dans une prise polarisée. Si elle n'entre pas complètement dans la prise, insérer dans l'autre sens. Si elle n'entre toujours pas correctement, contacter un électricien qualifié. Ne jamais utiliser de rallonge sauf si la fiche rentre dans la prise au complet. Ne pas modifier la fiche.

Fabriqué en Chine

Cher Client,

Félicitation sur votre achat de cette lampe. Elle a été construite avec des standards de qualité supérieure. Prenez le temps de lire soigneusement les précautions suivantes avant l'utilisation de cette lampe.

- En déballant et à l'assemblage, faites attention de pas tirer le fil trop fort, puisqu'une mauvaise connexion peut se produire.
- Ne seulement utiliser une même ampoule et avec un wattage spécifiés dans ces instructions ou sur l'étiquette placée sur la douille.
- N'essayez pas de remplacer l'ampoule pendant que la lampe soit branchée dans la prise électrique.
- Ne pas utiliser dehors, ou près de l'eau ou d'autres liquides.
- Débrancher de la prise électrique avant l'enlèvement de n'importe quelles pièces ou pour le nettoyage de la lampe.
- Seulement utiliser un tissu doux pour le nettoyage. Ne pas utiliser de nettoyeurs chimiques ou abrasifs.
- Enlever la couverture de cellophane du couvert d'ombre avant son usage.
- Pendant l'envoi du produit, le couvert de la douille a pu devenir détachée. Avant d'insérer l'ampoule, faites sure pour voir que le couvert de douille soit à sa place.