






KORO OUTDOOR COUNTER STOOL


17CS213A-W-SV

Assembly Instruction

Parts List:

REF.	PART NAME	PART IMAGE	Q'TY	REF.	PART NAME	PART IMAGE	Q'TY
A	CHAIR SEAT		1	D	METAL WASHER(ø12)		4
B	CHAIR LEG		1	E	ALLEN WRENCH		1
C	BOLT (1/4*15MM)		4				

Diagram



Assembly Steps:

- Step 1: Remove protective wrapping and lay all parts on floor. Identify all parts packed in carton against attached parts list to make sure all parts are presented.
- Step 2: Place a protective soft material on the floor, then lay SEAT (A) upside down on floor, the bottom is facing up.
- Step 3: Then attach CHAIR LEG (B) to the bottom as shown in Diagram, using BOLT(C) and WASHER(D).
- Step 4: After all bolts are aligned properly, tighten all bolts using WRENCH(E). With a second person's carefully turn the chair over onto its legs. Make sure legs rest on a flat surface.

NOTE: IT IS USER'S RESPONSIBILITY TO MAKE SURE ALL PARTS ARE ASSEMBLED AND TIGHTENED PROPERLY AND SECURELY.