


















Assembly Instruction

Item NO:PRO#412

NO	Description	Sketch	Q'TY	NO	Description	Sketch	Q'TY
A	Allen Wrench 4mm		1	M	Connecting Dowel Screw 6*35		2
B	Allen Wrench 2.5mm		1	N	Connecting Cam Fitting Ø15*12		2
C	Touch up Pen		2	O	Flathead Wrench		1
D	Ladder Rail Coupler		1	P	Allen Wrench 4mm For Electric Drill		1
E	Ladder Rail Finial		2	Q	Connector Bolt Ø2.5mm		2
F	Wall Strap		1	R	Wire buckle		2
G	Connector Bolt Ø1/4**1"		46	S	Screw M6*3/8"		2
H	Connector Cap Ø1/4**5/8"		18				
I	Bolt Ø1/4**1-5/8"		3				
J	Decoration Bolt Cap		3				

