



ELYSSA DINING SIDE CHAIR

275786

Assembly instructions:

PARTS LIST

SKU#	DESCRIPTION	IMAGE	Q'TY
2000	CHAIR BACK		1
2100	SEAT BOX W/ SEAT CUSHION		1
2200	FRONT LEG		2

HARDWARE LIST

SKU#	DESCRIPTION	IMAGE	Q'TY
2575	LONG BOLTS (Ø1/4"x 75mm)		4
2560	MEDIUM BOLTS (Ø1/4"x 60mm)		4
2540	SHORT BOLTS (Ø1/4"x 40mm)		2
2510	SPRING WASHERS (Ø1/4"x 10mm)		10
2519	FLAT WASHERS (Ø1/4"x 19mm)		10
7777	ALLEN KEY		1

NOTE: PO# is located underneath/ at the back side is it item. Please be prepared to provide this # should any claim be necessary.

CAUTION: Item is heavy. Assembly should be performed by two people.

