











1	PD5333-66CB		X1
2	PD5333-66LG1		X1
3	PD5333-66LG2		X1
4	PD5333-66SE		X2
A	PD5333-66HD-A		X8
B	PD5333-66HD-B		X8
C	PD5333-66HD-C		X8
D	PD5333-66HD-D		X1




AINSLEY



1



2



282673
D5333-66 HOST SIDE CHAIR



WARNING:
ONLY USE THE HAND
TOOLS PROVIDED