
## eurøstyle.

Assembly Instructions Dirk High Back Office Chair





C (1 pc)


-




 $\bigcirc \bigcirc \bigcirc$ 

D (1 pc)





During assembly, hand tighten screws only. When all screws are in place, then tighten completely.



PLEASE NOTE: Check that you have received all components and hardware before assembling. If you are missing any parts, contact your retailer, or fax Euro Style at 415.455.8033.