


ASSEMBLY INSTRUCTIONS & PARTS IDENTIFICATION MODEL # 652-60 DINING TABLE

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment

| Key Parts | | | | |
|-----------|-----------|-------|--------------|--|
| No | Code | Qty | Description | |
| 1 | 652-60P24 | 1 pc | Table Top | |
| 2 | 652-60P02 | 4 pes | Table Leg | |
| 3 | 652P01F | 4 pes | Floor Glide | |
| 4 | 652-60P26 | 4 pcs | Corner Block | |

| Hardware kit 652-60P01 | | | | | |
|------------------------|---|-------------|-------|--|--|
| No | | Qty | | | |
| A | 0 | Flat washer | 8 pcs | | |
| В | 0 | Lock washer | 8 pcs | | |
| C | • | Nut #M8 | 8 pcs | | |
| D | 2 | Key wrench | 1 pc | | |



STEP 1

- Carefully lay Table Top upside down on a smooth flat surface to prevent scratches.
- Attach each Leg to each corner of the Table Top as shown in illustration, Insert a Flat Washer, Lock Washer and Nut on to the insert nut of each Leg

 - Once all Legs are in place, fully tighten nuts by turning clockwise using provided Key Wrench until secure.