



LIVING SPACES

June, 2021

FL3224G-B62 / FL3224G-X12 **OFFICE CHAIR**





FEATURES

- **PNEUMATIC SEAT HEIGHT ADJUSTMENT**


To raise seat remove pressure from seat and pull lever (1) up.

To lower seat height sit on chair and pull lever (1) up.


NOTE: It is normal for chair to slightly lower under body weight.

1. Do not use this product unless all screws and bolts are securely tightened.
2. Check that all screws and bolts are tight every three months or as needed.
3. Dispose of packing material properly. Do not use plastic cover as head covering. It may cause suffocation.
4. Do not use this product as a stepladder.
5. Use this product for its intended purpose only.
6. **FOR INDOOR RESIDENTIAL USE ONLY.**


PARTS



(A) Chair Body (1 PC)




(B) Base (1 PC)



(C) Pneumatic Cylinder (1 PC)

STEP 1



APPLY DOWNWARD PRESSURE