





LIVING SPACES


| | | | |
|---|-------------|--|----|
| 1 | PB5406-01CB | | X1 |
| 2 | P99-00R | | X1 |

TOOLS REQUIRED (NOT PROVIDED):
PHILLIPS SCREW DRIVER

REMI




STANDARD STEP TO REMOVE DRAWER



LEVEL ME



286647
B5406-01
DRAWER NIGHSTAND



NOTE:
THE TABLE OR CASE SHOULD BE LOCKED IN POSITION AND LEVELLED USING A SPIRIT LEVEL.
(SPIRIT LEVEL NOT INCLUDED)