

*ASSEMBLY INSTRUCTIONS*  
*COASTER FINE FURNITURE*



*Fine Furniture for every stage of life*

**703738**  
**COFFEE TABLE**

REVISION 0 : 09/11/2017  
REVISION 1 : 08/16/2019

ITEM: 703738



# ASSEMBLY INSTRUCTIONS


## ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



### WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME 70 MINUTES

## PARTS IDENTIFICATION

A	TOP GLASS		1PC
B	SIDE FRAME		2PCS
C	TOP CROSSBAR		2PCS
D	BOTTOM CROSSBAR		1PC

## HARDWARE IDENTIFICATION

1	BOLT (1/4" x 15mm SR)		8PCS	3	CAP (30 x 30mm)		4PCS
2	SUCTION CUP (9mm)		6PCS	4	ALLEN WRENCH (4mm)		1PC


ITEM: 703738

# ASSEMBLY INSTRUCTIONS




## STEP 1



Do not tighten until each step is completed or instructed.



## STEP 2



COMPLETE



# ITEM: 703738 ASSEMBLY INSTRUCTIONS



**Product Size : 1200 X 603 X 483 H (MM)**

**Product Size : 47  $\frac{1}{4}$ " X 23  $\frac{3}{4}$ " X 19"**

