

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

704989ii SOFA TABLE

REVISION 0:09/12/2017 REVISION 1:06/18/2020

PAGE 1 OF 5

COASTERFURNITURE.COM

ITEM:704989ii ASSEMBLY INSTRUCTIONS




ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME 28 MINUTES

PARTS IDENTIFICATION

Α	TOP GLASS						1PC
В	BOTTOM HALF MIRROR						1PC
С	SUPPORT FRAME						2PCS
D	CROSSBAR						4PCS
HARDWARE IDENTIFICATION							
1	BOLT (5/16" x 25mm)		6PCS	4	PLASTIC WASHER (5/16")		6PCS
2	SHORT BOLT (3/16" x 8mm SR)		8PCS	5	SUCTION CUP (Ø8mm)		4PCS
3	WASHER (5/16")		6PCS	6	FOOT PAD (ø 40 x 15mm)		4PCS
PAGE 2 OF 5 COASTERFURNITURE.CO							

ITEM:704989ii **ASSEMBLY INSTRUCTIONS**



SPRING WASHER (5/16")

6PCS

9 SMALL ALLEN WRENCH (4mm)




1PC

8 LARGE ALLEN WRENCH (5mm)



1PC

STEP 1 Do not tighten until each step is completed or instructed.




ITEM:704989ii


ASSEMBLY INSTRUCTIONS



STEP 2



STEP 3




PAGE 4 OF 5


COASTERFURNITURE.COM

ITEM:704989ii ASSEMBLY INSTRUCTIONS

Product Size : 1220 X 431 X 743 H (MM)

Product Size: 48" X 17" X 29 \frac{1}{4}"





Note: Dimension tolerance ±5%

PAGE 5 OF 5

COASTERFURNITURE.COM