


**ASSEMBLY INSTRUCTIONS**  
**COASTER FINE FURNITURE**



*Fine Furniture for every stage of life*

**931214**  
**End Table**

REVISION 1: 12/27/2019

ITEM: **931214**



# ASSEMBLY INSTRUCTIONS

## ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



### WARNING

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intend for commercial establishments.



ASSEMBLY TIME

20 MINUTES

## PARTS IDENTIFICATION

A TOP

1PC



B BOTTOM FRAME

1PC



C LEG


3PCS



## HARDWARE IDENTIFICATION

1 BOLT


1/4"x5/8"



6PCS

2 BOLT

1/4"\*1-1/4



3PCS

3 ALLEN KEY

4mm





1PC


ITEM: 931214

# ASSEMBLY INSTRUCTIONS





## STEP 1


1		6PCS
3		1PC





## STEP 2

### COMPLETE

2		6PCS
3		1PC



ITEM:931214



**Note:** Dimension tolerance  $\pm 5\%$