

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

101929 Counter Height Stool

REVISION 0: 08/19/2010 REVISION 1: 11/18/2011 REVISION 2: 09/26/2018 REVISION 3: 01/31/2019 REVISION 4: 06/14/2019

ITEM: 101929

COASTER

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

Α	LEG		4PCS
В	FOOTREST		1PC
С	SWIVEL PLATE WITH FRAME		1PC
D	SEAT CUSHION WITH FRAME		1PC
E	BACKREST		1PC
HARDWARE IDENTIFICATION			
1	SHORT BOLT (Φ1/4" x 1" - BLK)		4PCS
2	MEDIUM BOLT (Φ1/4" x 1-4.5/8" - BLK)		8PCS
3	LONG BOLT (Φ1/4" x 1-3/4" - RBW)		6PCS
4	LOCK WASHER (Φ1/4" - BLK)	<u> </u>	14PCS
5	FLAT WASHER (Φ1/4" - BLK)	0	14PCS
6	ALLEN WRENCH (4MM - BLK)		1PC

NOTE:


Quantities shown are for one stool.

ITEM:101929




ASSEMBLY INSTRUCTIONS

STEP 1



STEP 2



PAGE 3 OF 4


COASTERFURNITURE.COM

ITEM:101929




ASSEMBLY INSTRUCTIONS

STEP 3



STEP 4



STEP 5 COMPLETE





PAGE 4 OF 4

COASTERFURNITURE.COM