


# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

192029 Counter Height Chair

REVISION 0: 11/20/2018 REVISION 1: 12/12/2020

PAGE 1 OF 5

COASTERFURNITURE.COM



#### **ASSEMBLY INSTRUCTIONS**

#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### **WARNING!**

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

30 MINUTES

#### PARTS IDENTIFICATION

Α	BACK FRAME		1PC
В	LEFT FRONT LEG		1PC
С	RIGHT FRONT LEG	•	1PC
D	FRONT STRETCER		1PC
E	RIGHT SIDE STRETCHER		1PC
F	LEFT SIDE STRETCHER		1PC
G	SEAT WITH FRAME		1PC

#### HARDWARE IDENTIFICATION

1	ALLEN WRENCH (M4 x 110mm - BLK)		1PC
2	LONG BOLT (M6 x 80mm- RBW)		4PCS
3	MEDIUM BOLT (M6 x 60mm- RBW)		4PCS
4	SHORT BOLT (M6 x 40mm- RBW)		2PCS
5	LOCK WASHER (1/4" - BLK)		10PCS
6	FLAT WASHER (1/4" - RBW)		10PCS
7	PAN HEAD SCREW (#8 X 1 1/2" - BLK)	<i>&lt;</i> ( <del>}</del>	6PCS

#### NOTE:


Phillips head screw driver is required in the assembly process; However, manufacturer does not provide this item. Quantities shown are for one chair.


COASTERFURNITURE.COM



#### **ASSEMBLY INSTRUCTIONS**

### STEP 1







# COASTER

#### **ASSEMBLY INSTRUCTIONS**

#### STEP 3





# COASTER\*

#### **ASSEMBLY INSTRUCTIONS**

STEP 5

**COMPLETE** 





