

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

100295 29" BAR STOOL

REVISION 0:08/18/2017 REVISION 1:07/09/2019 REVISION 2:06/02/2020

PAGE 1 OF 6

COASTERFURNITURE.COM



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.

ASSEMBLY TIME 20 MINUTES

PARTS IDENTIFICATION


Α	SEAT AND BACK		1PC
В	LEFT FRAME		1PC
С	RIGHT FRAME		1PC
D	TOP CROSSBAR		2PCS
E	BOTTOM CROSSBAR		2PCS
		_	

HARDWARE IDENTIFICATION				
1	SHORT BOLT (1/4" x 12mm SR)		4PCS	
2	LONG BOLT (1/4" x 35mm SR)		4PCS	
3	WASHER (ø16mm)		8PCS	
4	PLASTIC WASHER (ø16mm)		4PCS	
5	SPRING WASHER (1/4")		8PCS	
6	NUT (1/4")		4PCS	
7	CAP (25 x 25mm BLK)		4PCS	
8	HEX CAP HEAD BOLT (1/4" x 27mm)		4PCS	
9	ALLEN WRENCH (4mm)		1PC	
NOTE: PARTS LISTED ABOVE ARE FOR ONE CHAIR				




STEP 1

Do not tighten until each step is completed or instructed.










STEP 3 COMPLETE




How to clean Acrylic product:
Using a dry soft microfiber cloth, lightly brush off any dust.
For additional care, dampen the cloth with warm water.
For deepest cleaning, use an Acrylic cleaner.



Product Size: 432 X 533 X 1168 H (MM)

Product Size: 17" X 21" X 46"

The thickness of the metal is:1.2mm)
The thickness of the acrylic is:12mm)



Note: Dimension tolerance ±5%