

ASSEMBLY INSTRUCTIONS


5682BLK-24, 5682BRW-24, 5682GEN-24, 5682GRY-24, 5682RED-24 24 COUNTER HEIGHT STOOL


Important note :

- Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid scratching the parts.
- Kindly follow the assembly instructions step by step.
- Do not tighten all screws and bolts until the stool is fully assembled.


NO	COMPONENT	QTY
1	CUSHION SEAT	1
2	#2 FRONT LEG	2
3	#3 FRONT LEG	2
4	LONG STRETCHER	2
5	SHORT STRETCHER	2

NO	HARDWARE		QTY
А	BOLT Ø5/16" x 20 x 2"		8
В	SCREW Ø4 x 40mm	()	8
С	SPRING WASHER	Ĉ	8
D	FLAT WASHER	Ø	8
Е	ALLEN KEY		1






STEP 3



STEP 4



For items use on wooden floor, hard surfaces or carpets, it is recommended to Install protective pads under all legs and supports to avoid/prevent from damages/scratches and discoloration.