Tri-pod Floor Lamp LS9TRIPFLAB, LS9TRIPFLNI & LS9TRIPFLOB

SAFETY, ASSEMBLY, CARE, AND TROUBLESHOOTING

Important Safety Instructions:

TO REDUCE THE RISK OF FIRE, ELECTRICAL SHOCK, AND PERSONAL INJURY:

This lighting fixture is for indoor use only. This lamp is equipped with a polarized plug. One plug blade is wider than the other. DO NOT MODIFY the plug or power cord in any way.

DO NOT EXCEED the recommended bulb wattage. Use only the type of bulb specified. Keep flammable materials away from bulb. DO NOT OPEN the product or alter the wiring in any manner. Extension cord: Follow precautions provided with power cord.

UNPACKING: Use care when unpacking. Locate ALL PARTS INCLUDED before disposing of packaging materials.

Parts Included: Refer to Figure 1.

- 1. LAMP BODY (A)
- 2. TUBE (B) x 3
- 3. TUBE (C) x 3
- 4. TUBE (D) x 3
- 5. SOCKET (E)
- 6. SHADE (F)
- 7. LOCKING NUT(G)
- 8. LIGHT BULB (H) (NOT INCLUDED)
- 9. ON/OFF FOOT SWITCH (I)
- 10. CORD WITH PLUG (J)

Assembly Procedure: Refer to Figure 1.


- 1. Attach Tube (B) to the threaded rod on Lamp Body (A) and twist until secure. Repeat this step until all 3 tubes are attached.
- 2. Attach Tube (C) to the threaded rod on Tube (B) and twist until secure. Repeat this step until all 3 tubes are attached.
- 3. Attach Tube (D) to the threaded rod on Tube (C) and twist until secure. Repeat this step until all 3 tubes are attached.
- 4. To attach the shade, remove the Locking Nut (G) by twisting until it is separated from the Socket (E). Place the center ring of the Shade (F) onto the Socket (E).
- 5. Secure the Shade (F) by placing the Locking Nut (G) back onto the Socket (E) and twist until secure.
- 6. Install Light Bulb (H) to Socket (E).
- 7. Plug in 2-Prong Polarized Cord (J) into outlet.
- 8. Turn on lamp using the On/Off Foot Switch (I).

Care & Cleaning:

- 1. To clean, wipe with a soft, dry cloth.
- 2. DO NOT USE cleaners, scouring pads, etc.
- 3. Unplug lamp and allow bulb to cool before changing bulb.

Troubleshooting:

Problem:	Possible cause:	Correct by:
Bulb does not light	Bulb is burnt out or damaged	Replace bulb
	Power to lamp is off	Confirm power is on
	Lamp is not plugged in	Confirm lamp is plugged in



Tri-pod Floor Lamp LS9TRIPFLAB, LS9TRIPFLNI & LS9TRIPFLOB