








# LIVING SPACES

A	ML-7640-A		x1
B	ML-7640-B		x1
C	ML-7640-C		x1
D	ML-7640-D		x5



ML-7640/322065


LOKI BLACK & BLUE GAMING CHAIR



①



Scan QR code to view assembly video



②



③



④



While handle is pulled outward, tilt mechanism is unlocked and rocking motion is possible. To adjust force required during rocking:

- Turn the knob clockwise to make rocking easier.
- Turn the knob counterclockwise to make rocking more difficult.
- Adjust according to your weight or as desired.