OWNER'S MANUAL

MARIKO DRESSER MIRROR LIVING SPACES SKU: 323023 VENDOR ITEM NO.: MWNJ83



Scan QR code to view assembly video

ASSEMBLY PARTS LIST

SKU#	IMAGE	DESCRIPTION	QUANTITY	HARDWARE KIT PACKED IN BOX SKU: MWZZ83HW			
				SKU#	IMAGE	DESCRIPTION	QUANTITY
323023-1		MIRROR	1	MWZZ83HW-1		ALLEN BOLT (M6 X 50MM)	4
				MWZZ83HW-2	0	LOCK WASHER (M9)	4
MWNJ83MS		MIRROR SUPPORT	1				
				MWZZ83HW-3	(0)	FLAT WASHER (M8)	4
)	(=-=-)	
323022		DRESSER (sold separately)	1	MWZZ83HW-4		ALLEN KEY	1

FULLY ASSEMBLED



OWNER'S MANUAL

MARIKO DRESSER MIRROR LIVING SPACES SKU : 323023 VENDOR ITEM NO. : MWNJ83





Scan QR code to view assembly video


ASSEMBLY INSTRUCTIONS



OPTION 1: DRESSER MOUNTING







ASSEMBLY COMPLETE


OWNER'S MANUAL

MARIKO DRESSER MIRROR LIVING SPACES SKU : 323023 VENDOR ITEM NO. : MWNJ83




Scan QR code to view assembly video


ASSEMBLY INSTRUCTIONS




OPTION 2: WALL MOUNTING










MOUNTING HARDWARE

* WALL MOUNTING HARDWARE NOT INCLUDED





ASSEMBLY COMPLETE

OWNER'S MANUAL

MARIKO DRESSER MIRROR LIVING SPACES SKU : 323023 VENDOR ITEM NO. : MWNJ83



Scan QR code to view assembly video



WARNING:

- For wall mounting we recommend installing the mounting hardware into wall study or a board that is secured to study

ROUTINE MAINTENANCE:

Periodically check all fittings and tighten if necessary, as they can loosen over time.

CARE AND CLEANING:

GLASS:

Clean with a slightly damp cloth and dry immediately with a lint-free cloth. Use only mild detergents and cleaning solutions which are recommended for cleaning glass. Use coasters and placemats on glass table tops to prevent marking on the surface of your product.

SOLID WOOD FURNITURE:

Congratulations on purchasing this handcrafted solid wood furniture product. Please keep in mind that wood is sensitive to changes in humidity. As the weather changes so does the relative humidity in your home and the moisture content of your solid wood furniture. We have taken every precaution to stabilize the lumber used to build this product. Still, you may observe plank movement or small cracks as the seasons change, particularly during the first 6-12 months of ownership. This is normal for solid wood furniture and will not affect the performance or longevity of this product.

Dust frequently with a clean, damp, lint-free cloth. Frequent dusting will remove abrasive build-up which can damage a finish over time. Avoid using oily polishes or waxes. Avoid exposing your furniture to strong sunlight. Prolonged exposure to direct sunlight can fade the finish of your furniture. Do not expose your furniture to any liquids. Never allow water to sit on your furniture. Do not place hot items on top of surface, always use a mat or other protector. Alcohol, nail polish and perfume are also dangerous, as they can dissolve the furniture finish on contact and may require professional repairs