

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

REVISION 0: 12/08/2021

753538 Coffee Table

ITEM: **753538**



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

A TOP 1PC

B LEG 3PCS

C CROSSBAR 1PC

HARDWARE IDENTIFICATION

1 BOLT (JCBB M8 X 50mm) 6PCS


2 ALLEN WRENCH 1PC

3 WOOD PLUG 6PCS


ITEM:**753538**

COASTER


ASSEMBLY INSTRUCTIONS STEP 1




STEP 2



STEP 3



STEP 4
COMPLETE






COASTERFURNITURE.COM

PAGE 3 OF 3

TEM:**753538**





Note: Dimension tolerance ±5%