



Assembly Instructions


WESLEY Coffee Table





PLEASE NOTE: Check that you have received all components and hardware before assembling. If you are missing any parts, contact your retailer.





Note: 1. Check that the screws are inserted into the correct holes. 2. Tighten the screws hand tight. 3. Do not over-tighten the screws.






A (2 pcs)
M8 x 300


B (2 pcs)
Ø10x40


C (1 pc)
M8


D (2 pcs)
M8


E (2 pcs)
Ø8




F (2 pcs)
Ø8

During assembly, hand tighten screws only. When the screws are in place, tighten completely.

Assembly Instructions

WESLEY Coffee Table

PLEASE NOTE: Check that you have received all components and hardware before assembling. If you are missing any parts, contact your retailer.



NOTE: If the table is wobbly, the plastic feet (6 pcs) can be adjusted as needed. Turn right to bring the feet in, or turn left to bring the feet out more.