





CANNON OUTDOOR LOUNGE CHAIR

22C180A-W

326704

Assembly Instruction

Parts List:

REF	DESCRIPTION	IMAGE	QTY
A	SEAT		1
B	BACKREST		1
C	BACK CUSHION		1
D	CUSHION		1

Hardware List:






REF	DESCRIPTION	IMAGE	QTY
060	Bolt (1/4"*40MM)		2
093	Washer (M6,IDΦ6.5,ODΦ14)		2
050	Allen Wrench (1/4")		1

Diagram:

step 1



step 2



step 3

