

ASSEMBLY INSTRUCTIONS


ITEM NO: B8270 / B8280 - 4 CHEST

BOX OF CHEST

ITEM	DRAWING	DESCRIPTION	QTY
A		CHEST	1
В		FRONT LEG (WITH "F/L" LABEL)	1
С		FRONT LEG (WITH "F/R" LABEL)	1
D		BACK LEG (WITH "B/L" LABEL)	1
E		BACK LEG (WITH "B/R" LABEL)	1

ITEM	DRAWING	DESCRIPTION	QTY
1		ALLEN WRENCH (M4)	1
2	9 -99	CONNECTION BOLT (M6 x 60mm) W/WASHER & SPRING WASHER	4
3		Assembly Tool Not Included	1





THE HARDWARE IS LOCATED IN THE PACKING ITEMS THE ANTI TIPPING HARDWARE IS LOCATED IN 1st DRAWER OF CHEST


NOTE: MUST TIGHTEN SCREWS PERIODICALLY. WITH USE SCREW MAY BECOME LOOSE. CHECK TIGHNESS OF ALL SCREW EVERY 6-8 WEEKS.

CLEANING INSTRUCTION



ITEM: B8270 / B8280 - 4 CHEST


ANTI-TIPPING KIT



This tip restraint must be attached to a wall stud using long screw enclosed.


STEP 1

Attach a bracket securely to the back top rail of the chest using short screw provided, through the smaller hole.



STEP 2

Locate the other bracket on the wall over a wall stud and two inches below the mounting bracket secured to the back of chest. Attached to the wall stud using the long screw provided, through the smaller hole.



STEP 3

Place the chest into position so both mounting brackets are vertically in line. Lace the end of the restraint strap through the large hole in each mounting bracket. Bring both ends together and slide the flat end through the locking end and draw it through until all slack is removed. Confirm that the strap is securely laced and locked.

