







1	PD5491-20TP		x1
2	PD5491-20TL		x1
3	PD5491-20LG		x2
4	PD5491-20MP		x2
5	PD5491-20ML		x2
6	PD5491-20SR		x2
A	PD5491-20-HD-A		x26
B	PD5491-20-HD-B		x26
C	PD5491-20-HD-C		x12
D	PD5491-20-HD-D		x8
E	PD5491-20-HD-E		x2
F	PD5491-20-HD-F		x2
G	PD5491-20-HD-G		x2
H	PD5491-20-HD-H		x1
I	PD5491-20-HD-I		x1

HARLY



330020 / D5491-20
EXT. FARMHOUSE DINING TABLE



WARNING:
ONLY USE THE HAND
TOOLS PROVIDED