


ASSEMBLY INSTRUCTIONS & PARTS IDENTIFICATION MODEL # 2271-SPADERWS

SPADER DINING TABLE

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment

| | KeyParts | | | | |
|----|-------------------|-------|-------------|--|--|
| No | Code | Qty | Description | | |
| 1 | 2271-SPADERWSP24 | 1 pc | Table Top | | |
| 2 | 2271-SPADERWSP02 | 4 pes | Legs | | |
| 3 | 2271-SPADERWSP01F | 4 pes | Floor Glide | | |

| Hardware kit 2271-SPADERWSP01 | | | | |
|-------------------------------|-------------|---------------|-------|--|
| No | Description | | Qty | |
| A | 0 | Flatwasher | 8 pcs | |
| В | 0 | Lockwasher | 8 pcs | |
| C | (8) | Nut 8x15mm | 8 pcs | |
| D | 3==3 | Wrench15x16mm | 1 pcs | |



- Carefully lay Table Top upside down on a smooth flat surface to prevent scratches.
- Attach each Leg to each corner of the Table Top as shown in illustration. Insert a Flat Washer, Lock Washer and Nut on to the insert nut of each Leg
- Once all Legs are in place, fully tighten nuts by turning clockwise using provided Wrench until secure.