








## ASSEMBLY INSTRUCTIONS & PARTS IDENTIFICATION MODEL # 2301-RND42 RECLAMATION ROUND DINING TABLE

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment.

| Parts |             |       |              |
|-------|-------------|-------|--------------|
| No.   | Code        | QTY   | Description  |
| 1     |             | 1 PC  | Table Top    |
| 2     | 2301-RNDP02 | 4 PCS | Leg          |
| 3     | 2301P01F    | 4 PCS | Floor Glides |

| Hardware Kit (2301-RND42P01) |   |                   |        |
|------------------------------|---|-------------------|--------|
| No.                          |   | Description       | Qty    |
| A                            |  | Flat washer M8x18 | 20 pcs |
| B                            |  | Lock Washer M8    | 12 pcs |
| C                            |  | Bolt M8x30        | 4 pcs  |
| D                            |  | Bolt M8 x 45      | 8 pcs  |
| E                            |  | Wrench            | 1 pc   |
| F                            |  | Nut               | 8 pcs  |



- CAREFULLY LAY TABLE UPSIDE DOWN ON SMOOTH SURFACE TO PREVENT SCRATCHING.
- POSITION THE LEG IN THE BRACKET WITH A BOLT "D" AND A FLAT WASHER. PUT ALL THE BOLTS THROUGH THE LEGS IN EACH POSITION.
- ATTACH THE BOLT USING A FLAT WASHER, LOCK WASHER, AND A NUT. DO NOT FULLY TIGHTEN AT THIS POINT.
- ATTACH BOLT "C" WITH A LOCK WASHER AND A FLAT WASHER TO THE FRONT POSITION OF THE LEG AND TIGHTEN WITH THE WRENCH PROVIDED.
- TIGHTEN ALL NUTS FIRMLY.
- TWO PERSON REQUIRED TO FLIP THE TABLE

