













1	LS-D5877-63SE CHAIR SEAT WITH BACK REST	 X1
2	LS-D5877-63LG1 FRONT LEG	 X2
3	LS-D5877-63LG2 BACK LEG (RIGHT SIDE)	 X1
4	LS-D5877-63LG3 BACK LEG (LEFT SIDE)	 X1
A	PD5877-63HD-A	 X8
B	PD5877-63HD-B	 X8
C	PD5877-63HD-C	 X8
D	PD5877-63HD-D	 X1


**ASTRA**





333855/ LS-D5877-63  
UPH DINING CHAIR WITH BACK



**Step 1**



**Step 2**



**ASSEMBLY COMPLETED**



WARNING:  
ONLY USE THE HAND  
TOOLS PROVIDED