








Assembly Instructions


ITEM NO: 1208BUE-1

ACCENT CHAIR


Note: legs and hardware are packed and stored in the bottom of the seat, please take out for assembly.

PART	DRAWING	DESCRIPTION	QTY	PART	DRAWING	DESCRIPTION	QTY
A		CHAIR	1 PC	1		BOLT (Ø5/16" *1-1/4")	12 PCS
B		FRONT LEG	2 PCS	2		SPRING WASHER (Ø5/16")	12 PCS
C		REAR LEG	2 PCS	3		FLAT WASHER (Ø5/16")	12 PCS
				4		ALLEN KEY (M4)	1 PC


STEP 1:



STEP 2:



STEP 3: COMPLETED



CARE INSTRUCTION FOR FABRIC FURNITURE

In order to maintain the original appearance of your furniture, please follow below care procedures.

°Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Sunlight and / or exposure to heating and air conditioning outlets will fade/damage fabric. Do not place your upholstered furniture too close to windows, radiators, vents and be sure to use window treatments to block the sun's rays.

°Wipe with a soft brush to remove dust.