

LIVING SPACES

OWNER'S MANUAL

JAXON CAFE DRESSER
 LIVING SPACES SKU : 81478
 VENDOR ITEM NO. : 7YC982




Scan QR code to view assembly video

ASSEMBLY PARTS LIST

SKU #	IMAGE	DESCRIPTION	QUANTITY	HARDWARE KIT PACKED IN BOX SKU : 7YZZCPHW			
				SKU #	IMAGE	DESCRIPTION	QUANTITY
81478		DRESSER	1	7YZZCPHW-1		ALLEN BOLT (M6 X 50MM)	4
7YC9CPLG		LEG	4	7YZZCPHW-2		FLAT WASHER (M6)	4
7YC982CL		CENTER SUPPORT LEG	1	7YZZCPHW-3		ALLEN KEY	1
7YC982MS		MIRROR SUPPORT SET	1	RPZZCPTRDQP		TIPPING RESTRAINT	1

FULLY ASSEMBLED



PRE-ASSEMBLED PARTS LIST

SKU #	IMAGE	DESCRIPTION	SKU #	IMAGE	DESCRIPTION
7YZZCPHLS		SMALL HANDLE	7YZZCPFC18		FOOT CAP
7YZZCPHL		LARGE HANDLE	7YZZCPBTS		SMALL DECORATIVE BOLT
7YZZCPDG350		DRAWER GLIDE SET			

LIVING SPACES


OWNER'S MANUAL

JAXON CAFE DRESSER
LIVING SPACES SKU : 81478
VENDOR ITEM NO. : 7YC982






Scan QR code to view assembly video

ASSEMBLY INSTRUCTIONS



Not provided



ASSEMBLY COMPLETE

LIVING SPACES

OWNER'S MANUAL

JAXON CAFE DRESSER
LIVING SPACES SKU : 81478
VENDOR ITEM NO. : 7YC982



Scan QR code to view assembly video



WARNING:

- Maximum distributed load capacity: 240 lbs.
- Drawer capacity: 50 lbs. per drawer.
- Sitting, standing or jumping on this product may result in damage or injury.
- Injuries and damage can occur from furniture tip over if product is not properly anchored to the wall. Use the Furniture Tipping Restraint provided with the product.
- If the Furniture Tipping Restraint kit is not in the box, please contact our customer service department in order to obtain another kit before using the furniture.

ROUTINE MAINTENANCE:

Periodically check all fittings and tighten if necessary, as they can loosen over time.

CARE AND CLEANING:

SOLID WOOD FURNITURE

Congratulations on purchasing this handcrafted solid wood furniture product. Please keep in mind that wood is sensitive to changes in humidity. As the weather changes so does the relative humidity in your home and the moisture content of your solid wood furniture. We have taken every precaution to stabilize the lumber used to build this product. Still, you may observe plank movement or small cracks as the seasons change, particularly during the first 6-12 months of ownership. This is normal for solid wood furniture and will not affect the performance or longevity of this product.

Dust frequently with a clean, damp, lint-free cloth. Frequent dusting will remove abrasive build-up which can damage a finish over time. Avoid using oily polishes or waxes. Avoid exposing your furniture to strong sunlight. Prolonged exposure to direct sunlight can fade the finish of your furniture. Do not expose your furniture to any liquids. Never allow water to sit on your furniture. Do not place hot items on top of surface, always use a mat or other protector. Alcohol, nail polish and perfume are also dangerous, as they can dissolve the furniture finish on contact and may require professional repairs.